

## Installation Instructions: Spotlight (10370-10381)

### Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

### Important User Advice

- The ambient room temperature should not exceed 25°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing
- Max 35W GU10

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery.

Where possible recycle your packaging.  

Read these instructions before installation and retain for future reference 

This equipment should be installed by a competent electrician



Fig 2

### Installation

- Provide power to the required point of installation. Suitable IP rated junctions boxes should be used where required.
- To access terminal block, remove the mounting bracket by unscrewing the 2 screws (see Fig 1).
- Secure the fitting to the mounting bracket and fasten the 2 screws.
- Switch on and check for correct operation.
- Using the mounting bracket as a template mark the location of the fixing holes, and drill the holes ensuring not to infringe with any joists, gas or water pipes or electrical cables.
- Ensuring correct polarity is observed, carefully wire as shown in Fig 2.




Fig 1



Technical Helpline +44 (0)1924 893380

[www.bellighting.co.uk](http://www.bellighting.co.uk)

British Electric Lamps Ltd

Unit A Foxbridge Way, Normanton Industrial Estate  
Normanton, West Yorkshire. WF6 1TN

T: +44 (0)1924 893380 F: +44 (0)1924 894320 E: [sales@bellighting.co.uk](mailto:sales@bellighting.co.uk)

[www.bellighting.co.uk](http://www.bellighting.co.uk)