

Installation Instructions: Arial Downlight 10580/1/2

Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

- All tests should be carried out in accordance to EN 50172:2004.
- BELL will not accept responsibility for any claims arising from a poor installation.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery.

Where possible recycle your packaging.




NOT Insulation Coverable


Not suitable for covering with insulation material




Read these instructions before installation and retain for future reference


This equipment should be installed by a competent electrician






Part Code	Wattage	Voltage						сст
10580	9W	220- 240V~	50/60Hz	250mA	0.5	>80	-20~40°C	4000K
10581	12W			350mA	0.5			
10582	21W			500mA	0.9			







British Electric Lamps Ltd

Unit A Foxbridge Way, Normanton Industrial Estate Normanton, West Yorkshire. WF6 1TN