

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.



IEC 60598	IP65	$t_a 25^\circ\text{C}$		CE				ERC	
---------------------	-------------	------------------------	--	-----------	--	--	--	------------	--

Type / Tipe/ Loai / رقم النوع / Тип / Τύπος	CCT (K)	Power(W)/Daya/ Công suất/กำลังไฟฟ้า/ Мощность/Потужність /كوات/الطاقة	LEDs	Lumen Output (lm)/Lumen keluaran/Quang thông (lm) /лучи/Световой поток /Світловий потік /كوات/الطاقة	Dimension / Dimensi /Kích thước/Размер/Төр /Размеры/Разміри /Өлшемдері/الامتداد AxBxC (mm)	S.C. (m ²)	Voltage/Tegangan /Điện áp/Тәтәү Напряжение /Напряжение/كهربى الجهد	Frequency /Frekuensi /Тан сә /Γαυρά/Частота /Кернеу/التردد	Surge rating
Bell-Bamer 20W 220-240V WS	4000	20	28	1700	206x305x40	0.039	220-240V~	50/60Hz	1KV/2KV
	4000								
	4000								
	4000								
	4000								
Bell-Bamer 30W 220-240V WS	4000	30	42	2550	206x305x40	0.039	220-240V~	50/60Hz	1KV/2KV
	4000								
	4000								
	4000								
	4000								

IP65 Junction Box
* no supplied with product

H05RN-F 3x1.0 mm²
60245IEC57
N: Blue
L: Brown

The terminal block should be complying with EN60998-2-1/EN60998-2-2

0 ~340°

Fasten the bolt
Torque: Nm

	20W	30W
Torque(Nm)	3	3

Install the luminaire according to the national regulation and make sure it will not fall off.

Operation mode

Automatic operation

- The unit will light on when walking through the detection range
- Ambient Light: 3-2000LUX (adjustable)
Time-Delay: min: 10sec±3sec
max: 7min±3min
- SENS:<8M (adjustable)

Manual over-ride

- Light on for 5 seconds and switch off-on twice in 2 seconds. The unit will stay on bypassing the sensor.
- Turn off the light for 10 seconds, the unit will back to automatic operation mode.

Detection range

Installation Instructions -

-
-
-
-
-
-